TEMPERATURE SENSORS



Marine applications and heavy environments

Specifications:

APPLICATION SENSOR DESCRIPTION AND CATALOG SHEET no.

STORAGE

Coolers, containers.


Temperature Range -30 °C to +70 °C.

Cargo and inside storage rooms.

Temperature Range -30 °C to +60 °C.

Cargo temperature.

Temperature Range -30 °C to +60 °C.



Resistance thermometer for direct immersion.

Datasheet D/340.

Resistance thermometer for mounting on storage.


Datasheet D/340.

Resistance thermometer for penetration in cargo.
Datasheet D/340.

AIR

Ambient air in storage rooms.


Temperature Range -30 °C to +70 °C.



Wall mounting resistance thermometer.

Datasheet D/350.


Cooling vent pipes and storage rooms. Temperature Range -30 °C to +70 °C.



Direct immersion resistance thermometer with connection head.

Datasheet D/350.

Cooling vent pipes and storage rooms. Temperature Range -30 °C to +70 °C.



Direct immersion resistance thermometer with extension leads. Datasheet D/350.